#### LOGSIZE

#### USER MANUAL

+32 (0) 2 533 04 80 support@logsize.com



# Index

## About Logsize Android app

+32 (0) 2 533 04 80 support@logsize.com



# About Logsize

#### Log stack volume measurement in record time

#### Save time

With Logsize log stack volume measurement becomes incredibly fast. You can measure up to 1000 logs in a few minutes.

#### Get precise results

Logsize measures log stacks in a consistant way thus reducing human errors in measurement.

+32 (0) 2 533 04 80 support@logsize.com

#### Better data management

All your data is available online anytime and from any place. Multiple persons in the company can access the data and export it to the company's management systems.

@ FORDAQ

▲ LOGSIZE

# About Logsize

#### How it works





Start Logsize app

Photograph log stack with your device

The app determines the volume and no. of logs

+32 (0) 2 533 04 80 support@logsize.com





#### Data uploaded to web storage module

Access the measurements on your FMS or email

#### FORDAQ LOGSIZE

# Android app

#### Installation instructions



**Open Play Store** 



#### Search "Logsize"



#### Download the app

information about your compo
Company name
Key contact person
Phone

+32 (0) 2 533 04 80 support@logsize.com









#### Start measuring

#### FORDAQ LOGSIZE



+32 (0) 2 533 04 80 support@logsize.com



+32 (0) 2 533 04 80 support@logsize.com Click on "Start measuring" to begin using the measurement tool.





+32 (0) 2 533 04 80 support@logsize.com You can also watch an in-app tutorial by clicking on the right-top button.





+32 (0) 2 533 04 80 support@logsize.com Make sure that you have the camera parallel to the log stack and all the logs are included in the picture.

Left top side you have the tilt angles of the camera displayed. Hold your smart device at a 90+/-3 degree angle. If the tilt angles are too great for the picture, their background color will turn from green to red. So before you take the picture, confirm that the orientation sensor readings are green – otherwise you will not be able to save the photo.

FORDAQ

LOGSIZE



+32 (0) 2 533 04 80 support@logsize.com If there is not enough light in the picture, you can set the exposure to a value bigger than zero, between 0.5 - 2.0. If there is too much light, you can make it smaller by using the same EV filter with negative value between -0.5 and -2.0.

Lighter pictures have more accurate results than darker ones.

*GEORDAQ* LOGSIZE

+32 (0) 2 533 04 80 support@logsize.com You need to have a reference in the picture - a stick, piece of wood, etc for which you know exactly the height.

It is recommended to use references bigger than 100cm. The most accurate results are obtained with references bigger than 140cm.

*PORDAQ* LOGSIZE



+32 (0) 2 533 04 80 support@logsize.com Take the picture by tapping the camera button





+32 (0) 2 533 04 80 support@logsize.com If your device does not have GPS enabled, you will be prompted to save without location or add location manually.





+32 (0) 2 533 04 80 support@logsize.com If your device has GPS enabled, your location will be determined automatically.





You have now 2 options: "Save" the image without measuring (you can come back to it later) or "Measure and save".

+32 (0) 2 533 04 80 support@logsize.com



Diameter		Pile	Truck	Save P
				re
				ů
		000		anter //
	Reference size@	200 cm		-
	Tree species	Spruce		Т
	Log length@	300 cm		f
	Calculate using	Cylindrical formula		V
		Show advance	ed fields	f
		Save		
		Sure		F

+32 (0) 2 533 04 80 support@logsize.com ing on "Measure and save", you are ed to add different details needed: ce size, tree specie, log length and formula r volume.

oices are the GOST standard, the Nilson a (both are used when the pile is stacked thin ends in one direction) or the cylindrical a (used when the logs are mixed).

ne fields and click on "Save".

*GEORDAQ* LOGSIZE



+32 (0) 2 533 04 80 support@logsize.com You have to set on the picture the reference. The red line must be placed exactly on the reference you measured. Based on this, the diameters will be determined, so the 2 dots have to be set correctly for accurate results.

The top right corner of the screen will show a zoom view, to make finding the right position easier.

*CARDAQ* LOGSIZE



All round objects within the image may be detected, even if they are not part of the pile. For this reason an area of interested is defined and only the logs inside it are used to calculate the volume. Use the white markers to adjust the area borders

+32 (0) 2 533 04 80 support@logsize.com





+32 (0) 2 533 04 80 support@logsize.com Last step: fine-tuning. Here you can manually correct any errors which occured in the automatic measurements. You can remove, add or modify existing logs.





#### +32 (0) 2 533 04 80 support@logsize.com

By tapping on one of the existing circles, you can start editing it.





#### +32 (0) 2 533 04 80 support@logsize.com

The "+" icon lets you modify the dimension of the circle.

Using the "O" icon you can move the circle inside the image.





+32 (0) 2 533 04 80 support@logsize.com Long tapping one of the circles detected automatically deletes it.





Long tapping on an area where there is a log which was not determined will start the process of recognition and a new circle will be added on the picture, in that area.

+32 (0) 2 533 04 80 support@logsize.com You can then edit it to match the log exactly.

*GEORDAQ* LOGSIZE

← Measurement details





C Measure again

+32 (0) 2 533 04 80 support@logsize.com Clicking on "Next" will show the results of the measurement.



C Measure again		34Cm	ement details
	1	35cm	
	3	36cm	cultat 2016-03-03 10-06-19
	1	38cm	rage: Defront
	2	40cm	e: Uncate zed
	3	41cm	Like a
224	1	42cm	e species: id
JOH O	1	43cm	
.648.162.3	2	44cm	<u>ume.</u> 18,
46.1	1	45cm	62
47.148.640.7.43.7	3	46cm	
2 511 211 616 6	Av diameter_ 38.43cm 47cm 3		
2. 34 1. 244. 040. 048. 46. 3.2 4	3	48cm	count: 49
.648.162.3 46.1 47.148.640.743.7 2.511.244.646.648.46.132.4 541.745.64.41.262.520.24.07	1	49cm	length: 3m
14.7	1	52cm	erence size: 2m
	2	53cm	mula: Cylindrical
	1	62cm	
		ок	
		0	□

+32 (0) 2 533 04 80 support@logsize.com Tapping on "Av. diameter" link will show the detailed inventory with log diameters and count.





+32 (0) 2 533 04 80 support@logsize.com On the first screen, tapping on "View results" will show a list of all the measurements done, cronologically.





+32 (0) 2 533 04 80 support@logsize.com You can see a list with volumes for each one. By tapping on one of them, you will see all the details of that measurement.





+32 (0) 2 533 04 80 support@logsize.com Once the app is synced with the storage module, the results uploaded to the server are marked with "Uploaded".





+32 (0) 2 533 04 80 support@logsize.com In order to sync the app with the storage module, you can select "Sync now" in the options menu.

