



About Logsize

Log stack volume measurement in record time

Save time

With Logsize log stack volume measurement becomes incredibly fast. You can measure up to 1000 logs in a few minutes.


Get precise results

Logsize measures log stacks in a consistant way thus reducing human errors in measurement.

Better data management


All your data is available online anytime and from any place. Multiple persons in the company can access the data and export it to the company's management systems.







Web address: http://app.logsize.com

Login with the same credentials as on the Android app.






All the measurements done by your organisation's devices are stored in the storage module. Pictures can be viewed in table view (default) as well as map view. Users, devices, timber species and storages can be entered from Manage menu. Storages are synchronized with the device so all the information connected to storages and species will appear also in the device.




Information can be filtered according to specific storage, date, measurement type or storage status. By clicking on the name of the storage, different measurements stored under this specific storage will open.


You can see a list of measurements with details for each one: specie, volume, measurement date, log length.


By clicking on one result, you will see the full detailed report with picture, diameters and volumes.





You can see a list of measurements, with details for each one: specie, volume, when it was taken, log length






By clicking on the picture, you will be able to see the determined logs and filter them by diameter.


Here you can also see the geo-localization and all the details that were entered in the android app.

Users with admin rights can modify data (for example, change the volume formula, wood quality or assortment).



By clicking on "Save as Excel", you will download the results in a file which can be imported in your own CMS system.






Manage -> Storages

This page displays a list of your organization's available storages, as well as the location, status and last updates on them.


To add a new storage click "Add" from top right. A view will be displayed, where the name of storage, location and status can be inserted.



Manage -> Storages

You can also import storages from a CSV file.


For that select "Add from CSV" from top right. The CSV file needs to be in a correct format (name on every row, latitude, longitude).



Manage -> Timber


This page includes wood type, wood qualities, wood assortments and culls. All information is synchronized with the device, so all the options will also appear in the device.

Adding new wood types or wood qualities is taking place from top right, "Add wood type" or "Add wood quality".



Manage -> Devices

This page displays all the devices connected to the account. You can add or unlink devices and see the number of measurements for each device.




Manage -> Devices

Once you click on "Add device", there are 3 different options:

- Download Logsize through the link that is opened in the device;
- Send installing instructions to email;
- Install Logsize through Google Play and enter the company code displayed here.






Manage -> Users

You can see a list of all the users linked to your organization.


In order to add a new user, click on topright "Add user" button.



Manage -> Users


You can see a list of all the users linked to your organization. In order to add a new user, click on top-right "Add user" button.

To change the role of one user, click on the user's name and the detailed view on his data will appear. Users can be Administrators, Regular users or Measurers.



Manage -> Users


After clicking on "Add user", you will be prompted to add the name, email, password and timezone of the new user.



By clicking on Reports, you can see all the custom reports which you made.

You can make a new report by clicking on "New report" button.


For this, you have to create wood assortments prior to generating a report.



Next step will be clicking on New report.

Enter the name of the report and select the formula that is used in calculating the volume.

You will have to add measurements to the report by clicking on "Add to report" in your dashboard.



After completing the steps, you can export your report to pdf or view them at any time.